

Dismounting the door of Scan 85 and Scan 85 Maxi

Lift the top plate from the stove.




Dismount three screws.



Lift the top module off the stove or put an object between the top module and the stove.



Dismount three screws and bushings in order to remove the guide plate for the door. Be careful with the bushing in which the screw is fastened underneath the guide plate – this bushing is loose (see picture # 6).



Dismount the guide plate for the door.



Be careful not to lose this bushing, when the guide plate is dismantled.



Activate the handle and lift off the door.

